



### 1 - HEIGHT ADJUSTMENT LEVER

#### To raise

With the right hand, pull lever up while taking your weight off chair

—

#### To lower

With the right hand, pull lever up while seated



### 2 - SEAT DEPTH ADJ. LEVER

#### To move forward / backward

With the right hand, pull lever up and, using your body weight, bring the seat to the desired position



### 3 - TILT LOCK / UNLOCK LEVER

#### To lock tilt recline

Bring the backrest to the desired position using your body weight and, with the left hand, push lever down

—

#### To unlock tilt recline

With the left hand, pull lever up and unlock the tilt using your body weight



### 4 - TENSION ADJUSTMENT CRANK

#### To increase

With the right hand, extract crank and rotate it forwards

—

#### To decrease

With the right hand, extract crank and rotate it backwards

PRODUCT NAME

**Epron Plus Trasla**

TYPE

**Synchro tilt mechanism**

FEATURES

**Height adjustment**

—

**Comfort adjustment**

—

**Tilt lock**

—

**Seat depth adjustment**