



1 - HEIGHT ADJUSTMENT LEVER

To raise

With the right hand, pull lever up while taking your weight off chair

—

To lower

With the right hand, pull lever up while seated



1 - TILT LOCK / UNLOCK LEVER

To lock tilt recline

With the right hand, pull lever backwards

—

To unlock tilt recline

With the right hand, pull lever forwards



3 - TENSION ADJUSTMENT LEVER

To increase the tension

Turn the lever right

—

To decrease the tension

Turn the lever left

PRODUCT NAME

**Epsilon Comfort
adjustment**

TYPE

**Weight activated
mechanism**

FEATURES

Height adjustment

—

Tilt lock

—

Comfort adjustment