



### 1 - HEIGHT ADJUSTMENT LEVER

#### To raise

With the right hand, pull handle outwards while taking your weight off chair

—

#### To lower

With the right hand, pull handle outwards while seated



### 2 - TENSION ADJUSTMENT LEVER

#### To increase the tension

Turn the lever right

—

#### To decrease the tension

Turn the lever left



### 3 - TILT LOCK / UNLOCK LEVER

#### To lock tilt recline

With the left hand, pull handle outwards while taking your weight off chair

—

#### To unlock tilt recline

With the left hand, push lever inwards and unlock the tilt using your body weight



### 4 - SEAT DEPTH ADJ. LEVER

#### To move forward / backward

With the right hand, pull handle outwards and, using your body weight, bring the seat to the desired position

#### PRODUCT NAME

**Epsilon Integrated seat Comfort adjustment**

#### TYPE

**Weight activated mechanism**

#### FEATURES

**Height adjustment**

—

**Tilt lock**

—

**Seat depth adjustment**

—

**Comfort adjustment**