




1 - HEIGHT ADJUSTMENT LEVER

To raise

With the right hand, pull lever up while taking your weight off chair

—

To lower

With the right hand, pull lever up while seated



2 - TILT LOCK / UNLOCK LEVER

To lock tilt recline

With the left hand, push button inward

—

To unlock tilt recline

With the right hand, push button inward

PRODUCT NAME

Password

TYPE

Tilt mechanism with lock

FEATURES *

Height adjustment

—

Tilt lock

[*] THE FEATURES MAY DIFFER
ACCORDING TO THE TYPE OF
SELECTED PRODUCT