



### 1 - HEIGHT ADJUSTMENT LEVER

#### To raise

With the right hand, pull lever backwards while taking your weight off chair

—

#### To lower

With the right hand, pull lever backwards while seated



### 2 - TILT LOCK / UNLOCK LEVER

#### To lock tilt recline

Bring the backrest to the desired position using your body weight and, with the left hand, pull lever forwards

—

#### To unlock tilt recline

With the left hand, pull lever forwards to unlock the tilt

PRODUCT NAME

**Friendly 2 Lounge**

TYPE

**Weight activated mechanism**

FEATURES \*

**Height adjustment**

—

**Tilt lock**

[\*] THE FEATURES MAY DIFFER ACCORDING TO THE TYPE OF SELECTED PRODUCT