



1 - ARMREST HEIGHT ADJUSTMENT BUTTON

To raise

Push button and pull arm up to desired height

—

To lower

Push button and pull arm down to desired height



2 - PAD DEPTH AND WIDTH ADJUSTMENT SYSTEM

To move forward

Push PAD to desired position

—

To move backward

Pull PAD in to desired position



2 - PAD ROTATION ADJUSTMENT SYSTEM

To rotate

Rotate the PAD to the desired position



3 - ARMREST WIDTH ADJUSTMENT SYSTEM

To unlock

Loose the provided fixing lever

—

To lock

Tighten the provided fixing lever

PRODUCT NAME

Nedo

TYPE

Adjustable armrest

FEATURES

Armrest height adjustment

—

Armrest width adjustment

—

PAD rotation

—

PAD depth adjustment

—

PAD rotation