



1 - ARMREST HEIGHT ADJUSTMENT BUTTON

To raise

Push button and pull arm up to desired height

—

To lower

Push button and pull arm down to desired height



2 - PAD DEPTH ADJUSTMENT SYSTEM

To move forward

Push PAD forward or back to desired position

—

To move backward

Pull PAD in or push out



3 - PAD WIDTH ADJUSTMENT BUTTON

To adjust

Push button and rotate the PAD to the desired position



4 - ARMREST WIDTH ADJUSTMENT SYSTEM

To unlock

Loose the provided fixing lever

—

To lock

Tighten the provided fixing lever

PRODUCT NAME

BeO 4D Trasla

TYPE

Adjustable armrest

FEATURES

Armrest height adjustment

—

Armrest width adjustment

—

PAD rotation

—

PAD depth adjustment