



1 - HEIGHT ADJUSTMENT BUTTON

To raise / lower

Push button with one hand while bringing backrest to the desired position with the other one

NOME PRODOTTO

Activa

TIPOLOGIA

Back bar

FUNZIONALITÀ

Backrest height adjustment