



1 - TILT LOCK / UNLOCK BUTTON

To lock tilt recline

Pull button forwards

—

To unlock tilt recline

Push button backwards



2 - HEIGHT ADJUSTMENT LEVER

To raise

With the right hand, pull lever up while taking your weight off chair

—

To lower

With the right hand, pull lever up while seated

PRODUCT NAME

**Armonico
Aluminium plate**

TYPE

Tilt mechanism

FEATURES *

Height adjustment

—

Tilt lock

[*] THE FEATURES MAY DIFFER
ACCORDING TO THE TYPE OF
SELECTED PRODUCT