



### 1 - HEIGHT ADJUSTMENT LEVER

#### To raise

With the right hand, pull lever up while taking your weight off chair

—

#### To lower

With the right hand, pull lever up while seated



### 2 - TILT LOCK / UNLOCK BUTTON

#### To lock tilt recline

Bring the backrest to the desired position using your body weight and, with the left hand, push lever down

—

#### To unlock tilt recline

With the left hand, pull lever up and unlock the tilt using your body weight



### 3 - TENSION ADJUSTMENT KNOB

#### To increase

Rotate knob clockwise

—

#### To decrease

Rotate knob counterclockwise

#### PRODUCT NAME

**D109**

#### TYPE

**Weight activated mechanism**

#### FEATURES

**Height adjustment**

—

**Comfort fine-tuning**

—

**Tilt lock**