



### 1 - HEIGHT ADJUSTMENT LEVER

#### To raise

With the right hand, pull handle outwards while taking your weight off chair

—

#### To lower

With the right hand, pull handle outwards while seated



### 2 - TILT LOCK / UNLOCK LEVER

#### To lock tilt recline

Bring the backrest to the desired position using your body weight and, with the left hand, pull lever outwards

—

#### To unlock tilt recline

With the left hand, pull lever outwards and unlock the tilt using your body weight



### 3 - SEAT DEPTH ADJ. LEVER

#### To move forward / backward

With the right hand, pull handle outwards and, using your body weight, bring the seat to the desired position

#### PRODUCT NAME

**Dopotutto Duo**

#### TYPE

**Weight activated mechanism**

#### FEATURES

**Height adjustment**

—

**Tilt lock**

—

**Seat depth adjustment**