



1 - SEAT ANGLE ADJ. LEVER

To bring the seat angle at 0° With the right hand, rotate lever forwards

To bring the seat angle to -4° With the right hand, rotate lever backwards



2 - TILT LOCK / UNLOCK KNOB

To lock tilt recline

Bring the backrest to the desired position using your body weight and, with the left hand, rotate knob forwards

To unlock tilt recline

With the left hand, rotate knob backwards and unlock the tilt using your body weight



3 - TENSION ADJUSTMENT KNOB

To increase

With the right hand, rotate knob forwards

To decrease

With the right hand, rotate knob backwards

PRODUCT NAME

Inedito Seat angle adjustment

TYPE

Weight activated mechanism

FEATURES

Height adjustment

Comfort fine-tuning

Tilt lock

Seat angle adjustment



4 - HEIGHT ADJUSTMENT LEVER

To raise

With the right hand, pull lever up while taking your weight off chair

To lower

With the right hand, pull lever up while seated