



1 - HEIGHT ADJUSTMENT LEVER

To raise

With the right hand, pull handle outwards while taking your weight off chair

—

To lower

With the right hand, pull handle outwards while seated



2 - SEAT DEPTH ADJ. LEVER

To move forward / backward

With the right hand, pull handle outwards and, using your body weight, bring the seat to the desired position



3 - TILT LOCK / UNLOCK LEVER

To lock tilt recline

Bring the backrest to the desired position using your body weight and, with the left hand, pull lever outwards

—

To unlock tilt recline

With the left hand, pull lever outwards and unlock the tilt using your body weight

PRODUCT NAME

Trasla 2 Cable

TYPE

Quick connection seat

FEATURES *

Seat depth adjustment

—

Height adjustment

—

Tilt lock

[*] THE FEATURES MAY DIFFER ACCORDING TO THE TYPE OF SELECTED PRODUCT