



1 - POLISHED ALUMINIUM COMPONENTS

For cleaning

Use soft cloth and glass cleaner. To polish, apply aluminium polishing paste wax following the instructions on the label.

For disinfection

The use of ethanol is recommended, while the use of sodium hypochlorite (0.1% - 0.5% sol.), hydrogen peroxide and benzalkonium chloride is not recommended.*



2 - NYLON PLASTIC COMPONENTS

For cleaning

Use soft cloth and non-abrasive neutral detergent. Do not use alcohol, solvent-based, acid or abrasive cleaners.

For disinfection

We recommend the use of sodium hypochlorite (0.1% - 0.5% sol.) or hydrogen peroxide.*



3 / 4 - PP / PU PLASTIC COMPONENTS

For cleaning

Use soft cloth and non-abrasive neutral detergent. Do not use alcohol, solvent-based, acid or abrasive cleaners

For disinfection (PP)

Denatured alcohol, sodium hypochlorite (0.1% - 0.5% sol.), ethanol (70% sol.), hydrogen peroxide (0.5% sol.) and benzalkonium chloride can be used.*

For disinfection (PU)

Denatured alcohol or ethyl alcohol in a maximum concentration of 5% is recommended.*

PRODUCT NAME
BeO 4D 12°

—
BeO Straight

TYPE
Adjustable armrest

MATERIALS
Polished aluminium

—
Nylon plastic

—
Polypropylene plastic

—
Polyurethane plastic

* Analysis of the effects resulting from the application of chemicals on product surfaces, performed by an accredited laboratory.

Before disinfecting the entire surface of any component, it is advisable to proceed with tests on a small part of the product.