



1 - NYLON PLASTIC COMPONENTS

For cleaning

Use soft cloth and non-abrasive neutral detergent. Do not use alcohol, solvent-based, acid or abrasive cleaners.

For disinfection

We recommend the use of sodium hypochlorite (0.1% - 0.5% sol.) or hydrogen peroxide.*



2 - POLYPROPYLENE PLASTIC COMPONENTS

For cleaning

Use soft cloth and non-abrasive neutral detergent. Do not use alcohol, solvent-based, acid or abrasive cleaners

For disinfection

Denatured alcohol, sodium hypochlorite (0.1% - 0.5% sol.), ethanol (70% sol.), hydrogen peroxide (0.5% sol.) and benzalkonium chloride can be used.*



3 - POLYURETHANE PLASTIC COMPONENTS

For cleaning

Use soft cloth and non-abrasive neutral detergent. Do not use alcohol, solvent-based, acid or abrasive cleaners

For disinfection

Denatured alcohol or ethyl alcohol in a maximum concentration of 5% is recommended.*

PRODUCT NAME

BeO 4D 12°

—
BeO 4D Straight

—
BeO 4D Trasla

TYPE

Adjustable armrest

MATERIALS

—
Nylon plastic

—
Polypropylene plastic

—
Polyurethane plastic

Before disinfecting the entire surface of any component, it is advisable to proceed with tests on a small part of the product.

* Analysis of the effects resulting from the application of chemicals on product surfaces, performed by an accredited laboratory.