



#### POLISHED ALUMINIUM COMPONENTS

##### For cleaning

Use soft cloth and glass cleaner. To polish, apply aluminium polishing paste wax following the instructions on the label.

##### For disinfection

The use of **ethanol** is recommended, while the use of **sodium hypochlorite**, **hydrogen peroxide** and **benzalkonium chloride** is not recommended. \*



#### PAINTED ALUMINIUM COMPONENTS

##### For cleaning

Use soft cloth and non-abrasive neutral detergent. Do not use alcohol, solvent-based, acid or abrasive cleaners

##### For disinfection

The use of **sodium hypochlorite** (0.1% - 0.5% sol.) is recommended, while the use of **hydrogen peroxide** is not recommended. **Denatured alcohol** and **ethanol** may generate some slight aesthetic changes. \*

**Before disinfecting the entire surface of any component, it is advisable to proceed with tests on a small part of the product.**

#### PRODUCT NAME

**Superleggero**

#### TYPE

**Fixed support**

—

**Swivel support**

#### MATERIALS

**Polished aluminium**

—

**Painted aluminium**

\* Analysis of the effects resulting from the application of chemicals on product surfaces, performed by an accredited laboratory.