

NYLON PLASTIC COMPONENTS

For cleaning

Use soft cloth and non-abrasive neutral detergent. Do not use alcohol, solvent-based, acid or abrasive cleaners.

For disinfection

We recommend the use of sodium hypochlorite (0.1% - 0.5% sol.) or hydrogen peroxide.*




POLYPROPYLENE PLASTIC COMPONENTS

For cleaning

Use soft cloth and non-abrasive neutral detergent. Do not use alcohol, solvent-based, acid or abrasive cleaners.

For disinfection

Denatured alcohol, sodium hypochlorite (0.1% - 0.5% sol.), ethanol (70% sol.), hydrogen peroxide (0.5% sol.) and benzalkonium chloride can be used.*



POLISHED ALUMINIUM COMPONENTS

For cleaning

Use soft cloth and glass cleaner. To polish, apply aluminium polishing paste wax following the instructions on the label.

For disinfection

The use of ethanol is recommended, while the use of sodium hypochlorite, hydrogen peroxide and benzalkonium chloride is not recommended.*



PAINTED ALUMINIUM COMPONENTS

For cleaning

Use soft cloth and non-abrasive neutral detergent. Do not use alcohol, solvent-based, acid or abrasive cleaners.

For disinfection

The use of sodium hypochlorite (0.1% - 0.5% sol.) is recommended, while the use of hydrogen peroxide is not recommended. Denatured alcohol and ethanol may generate some slight aesthetic changes.*

Before disinfecting the entire surface of any component, it is advisable to proceed with tests on a small part of the product.

PRODUCT NAME

Friendly 2

Friendly 2 Lounge

TYPE

Weight activated mechanism

MATERIALS

Nylon plastic

Polypropylene plastic

Polished aluminium

Painted aluminium

* Analysis of the effects resulting from the application of chemicals on product surfaces, performed by an accredited laboratory.