



POLISHED ALUMINIUM COMPONENTS

For cleaning

Use soft cloth and glass cleaner. To polish, apply aluminium polishing paste wax following the instructions on the label.

For disinfection

The use of ethanol is recommended, while the use of sodium hypochlorite, hydrogen peroxide and benzalkonium chloride is not recommended. *



PAINTED ALUMINIUM / STEEL COMPONENTS

For cleaning

Use soft cloth and non-abrasive neutral detergent. Do not use alcohol, solvent-based, acid or abrasive cleaners

For disinfection

The use of sodium hypochlorite (0.1% - 0.5% sol.) is recommended, while the use of hydrogen peroxide is not recommended. Denatured alcohol and ethanol may generate some slight aesthetic changes. *



POLYPROPYLENE PLASTIC COMPONENTS

For cleaning

Use soft cloth and non-abrasive neutral detergent. Do not use alcohol, solvent-based, acid or abrasive cleaners

For disinfection

Denatured alcohol, sodium hypochlorite (0.1% - 0.5% sol.), ethanol (70% sol.), hydrogen peroxide (0.5% sol.) and benzalkonium chloride can be used.*

PRODUCT NAME

MPD38 Steel plate

TYPE

Tilt mechanism

MATERIALS

Polished aluminium

—

Painted aluminium

—

Painted steel

—

Polypropylene plastic

Before disinfecting the entire surface of any component, it is advisable to proceed with tests on a small part of the product.

* Analysis of the effects resulting from the application of chemicals on product surfaces, performed by an accredited laboratory.